Wifi Repeater Aqprox

Models appRP01V2 y appRP02 de Approx

- 1.1. Video tutorial in Spanish
- 1.2. Key info
 - $^\circ$ Example output after the wizard is completed
- 1.3. Test connection
- 1.4. Unplug and plug again when needed

1.1. Video tutorial in Spanish

How to setup them:

```
https://www.youtube.com/watch?v=xzXrfXvhXY0^{\cite{tabular}}
```

1.2. Key info

- 1. Reset the repeater (pressing the tiny button in the device side with the help of a clip end, for instance) if you ever use it before with some other wifi connection.
- 2. Plug it into the electrical grid
- 3. Ensure that the slider burrton in the device is set to "repeater" mode.
- 4. Connect the ethernet cable to the repeater in one end, and to the computer in the other end.
- 5. Change your wired connection settings in your operating system to use manual IPv4 connection as:
 - ip: 192.168.100.2
 - netmask: 255.255.255.0
 - gateway: 192.160.100.253
- 6. Open a browser and visit the url http://192.160.100.253
- 7. Login with the default credentials provided (admin / admin)
- 8. follow the wizard on screen.
 - Choose your wifi connection
 - provide its password
- 9. save settings
- 10. wait for the connection to succeed
- 11. unplug ethernet cable from wifi repeater, and from computer
- 12. reset your computer to use the new wifi connection (even if for the computer it will show up as the same wifi name as before, but with better signal)

Example output after the wizard is completed

aqprox./			Languager English ~	
	Router Status		Router Status Help	
Running Status	System Info		You can use the Router Status screen to check the	
Setup Wizard	Hardware Version	V1.0.0	current settings and statistics for your router. This screen shows you the current settings. If something	
, and the second	Firmware Version	V1.0.0	needs to be changed, you will have to change it on	
Repeater Mode Settings	Product Name	300 Mbps WI-FI Extender	the relevant screen.	
	Work Mode	Repeater Mode	System Info: These are the basic information of the device.	
letwork Settings	Time and Date	1971-01-01 08:07:19		
Wireless Settings	LAN Port		Hardware Version: This is the current handware the router is using.	
	MAC Address	FC: F5		
Ianagement Function	IP Address	192.168.100.253	 Firmware Version: This is the current software the router is using. This will change if you upprede your touler. 	
	IP Subret Maak	255 255 255 0		
Logout	Wireless Client		if you upgrade your router.	
	Wireless Network Selected Name (SSID)	MEtra-Fi	 Product Name: The model of the device. 	
	Wreless Channel	2.412GHz- CH1	Work Mode: The work mode of the	
	WI-Fi Protected Setup(WPS)	ON	device. The device has four work modes/Client Mode. Router Mode. Broester	
	Wreless Security Mode	WPA2-PSK(AES)	modes(Client Mode, Router Mode, Repeater Mode and Bridge Mode), you can change the	
	Connect Status	Connected	work mode by the hardware switch.	
	Wireless Universal Repeater		Time and Date: The time of the device.	
	SSID of Extended Interface	MFbra-F	LAN Port. These are the current settings, as set in the LAN IP Setup screen.	
	Wreless Security Mode	WPA2-PSI(AES)		
			MAC Address. The physical address of the router, as seen from the LAN. IP Address of the note: IP Subret Mask. The subnet mask associate with the LAN IP address.	
			Wireless Client: These are the current settings, as set in the Wireless Client Function screen.	
			 Wireless Network Selected Name (SSID). 	

1.3. Test connection

On GNU/Linux, you can see the difference if you run wavemon on a terminal with the old wifi signal (before adding the wifi repeater, or while temporarily unplugging it), and compare with the wavemon output when the repeater is on.



1.4. Unplug and plug again when needed

Keep in mind, that those new settings (of the new wifi you configured) are stored in the wifi repeater. Therefore, if you unplugit from the electrical grid for some reason, and you plug it again later on, you don't need to repeat this same process: it will just work repeating the signal from your wifi access point as usual.

Enjoy!

Alias names for this page: aqprox | wifi repeater | WifiRepeater | appRP01V2